

Piano Installation

For Twilight Zone Pinball

1. You do not have to remove the clock for this installation but it will be easier if you do. There are two screws along the bottom rear of the clock that hold it to a metal bracket. It would also help if you just loosen the screws a little if you do not want to take them all the way out.
2. Remove the yellow and red lamp holders under the clock by taking out the two Phillips screws. Save the screws as you will need them for this installation.
3. Now is a good time to clean the red and yellow lamp-covers and replace the bulbs if they are darkening.
4. Note the screw on the front right of the piano slot bracket and the hole under the keyboard of the piano. The keyboard lip will line up and slightly overhang the metal bracket, and the screw head should go into the hole (cut out) under the keyboard. The right side of the piano (tapered) should end up in between the wiring connectors on the clock.
5. Mount the piano with the lamp screws by screwing them back into the original holes.
6. Slide the yellow and red bulbs (in the holders) into the two holes in the front of the piano. The yellow should be down and the red up. Slide them all the way in until you reach the holders. They will stay put. Remove the nut holding the cable clamp. Route the wires neatly along the back of the piano and through the cable clamp and replace the nut. Use care not to over tighten and spin the piano roll on the front of the piano.
7. Re-install the clock or tighten the screws if you did not remove it. The clock can rest on the piano.
8. The roll on the piano is made of rubber to deflect air-balls. If it gets dirty with use, it may be cleaned by wiping with a Q-tip lightly dampened with alcohol. Be careful not to spill any on the keyboard or the black keys may smear.